



## Chair City Supply Company

### Fasteners for Cabinet & Furniture Assembly, Type 17 Cutting Point



Size	Case Qty.	Phillips Nib T17 Zinc	Combo Nib T17 Zinc	Combo Nib T17 Black	Square Nib T17 Black	Square Nib T17 Zinc
#8 x 1"	11,000	16202	12147	12148	20868	19485
#8 x 1-1/4"	9,000	12707	12149	12150	18293	17481
#8 x 1-1/2"	7,000	12708	12152	12153	18294	17482
#8 x 1-5/8"	5,500	12709	12154	12155	20869	-
#8 x 1-3/4"	5,000	12710	18566	13790	-	17784
#8 x 2"	4,000	12711	12156	12157	18760	17483
#8 x 2-1/4"	3,000	12712	12424	12423	-	17390
#9 x 2-1/2"	2,500	12713	12158	12159	18295	17484
#9 x 3"	2,000	12714	12160	12161	18150	17685

Chair City Assembly Screws with a Type 17 cutting point are ideal for use where a quick start and less splitting are desired. The Type 17 point cuts it's way into the wood and the aggressive thread pattern yields high pull-out strength.

**Chair City HI-Torque Assembly Screws are made from a heavier gauge wire and go through a special heat treat process that gives them a breaking torque almost two times that of standard fasteners. If you are having any breakage problems, try the Hi-Torque line and eliminate breaking screws forever!**

#### Square Flat Head HI-Torque Assembly Screws

Size	Case Qty.	Black	Dry Lube	Yellow Zinc	Clear Zinc
#8 x 3/4"	15,000	19754	19780	19729	19705
#8 x 1"	10,000	19755	18519	19730	19706
#8 x 1-1/4"	7,500	19756	19781	19731	19707
#8 x 1-1/2"	5,000	19757	18513	19732	19708
#8 x 1-3/4"	4,000	19758	18515	19733	19709
#8 x 2"	3,500	19759	18509	19734	19710
#8 x 2-1/4"	3,000	19760	18520	19735	19711
#8 x 2-1/2"	2,500	19761	18510	19736	19712
#8 x 3"	2,000	22400	23232	23234	23233
#10 x 1-1/2"	4,000	-	18523	-	-
#10 x 1-3/4"	3,000	-	18525	-	-
#10 x 2"	2,500	-	18518	-	-
#10 x 2-1/2"	2,000	-	18514	-	-
#10 x 3"	1,500	-	18511	-	-

